

Maßstabänderungen

Originalmaßstab	Maßstab Kopie											
	1 : 1000	1 : 500	1 : 250	1 : 200	1 : 100	1 : 50	1 : 25	1 : 20	1 : 10	1 : 5	1 : 2	1 : 1
1 : 1000	1 x 100	1 x 200	2 x 200 1 x Z 125	2 x 200 1 x Z 125	3 x 200 1 x Z 125	8 x 141 1 x Z 125	10 x 141 1 x Z 125	10 x 141 2 x Z 125	12 x 141 2 x Z 125	14 x 141 2 x Z 125	16 x 141 3 x Z 125	18 x 141 3 x Z 125
1 : 500	1 x 50	1 x 100	1 x 200	1 x Z 249 1 x Z 125	2 x 200 1 x Z 125	6 x 141 1 x Z 125	8 x 141 1 x Z 125	8 x 141 2 x Z 125	10 x 141 2 x Z 125	12 x 141 2 x Z 125	14 x 141 3 x Z 125	16 x 141 3 x Z 125
1 : 250	2 x 50	1 x 50	1 x 100	1 x Z 125	1 x 249 1 x Z 125	4 x 141 1 x Z 125	6 x 141 1 x Z 125	6 x 141 2 x Z 125	8 x 141 2 x Z 125	10 x 141 2 x Z 125	12 x 141 3 x Z 125	14 x 141 3 x Z 125
1 : 200	2 x 50 1 x Z 50	1 x Z 40	1 x Z 80	1 x 100	1 x 200 1 x Z 125	4 x 141 1 x Z 125	6 x 141 1 x Z 125	6 x 141 1 x Z 125	8 x 141 1 x Z 125	10 x 141 1 x Z 125	12 x 141 2 x Z 125	14 x 141 2 x Z 125
1 : 100	4 x 50	2 x 50 1 x Z 80	1 x Z 40	1 x 50	1 x 100	1 x 200	2 x 200	4 x 141 1 x Z 125	6 x 141 1 x Z 125	8 x 141 1 x Z 125	10 x 141 2 x Z 125	12 x 141 2 x Z 125
1 : 50	4 x 50 1 x Z 80	3 x 50 1 x Z 80	2 x 50	2 x 50	1 x 50	1 x 100	1 x 200	1 x 249 1 x Z 125	4 x 141 1 x Z 125	6 x 141 1 x Z 125	8 x 141 2 x Z 125	10 x 141 2 x Z 125
1 : 25	5 x 50 1 x Z 80	4 x 50 1 x Z 80	3 x 50 1 x Z 80	3 x 50	2 x 50	1 x 50	1 x 100	1 x Z 125	1 x 249 1 x Z 125	4 x 141 1 x Z 125	6 x 141 2 x Z 125	8 x 141 2 x Z 125
1 : 20	5 x 50 1 x Z 64	4 x 50 1 x Z 64	3 x 50 1 x Z 64	3 x 50 1 x Z 80	2 x 50 1 x Z 80	1 x 40	1 x Z 80	1 x 100	1 x 200	2 x 200	6 x 141 1 x Z 125	8 x 141 1 x Z 125
1 : 10	6 x 50 1 x Z 64	5 x 50 1 x Z 64	4 x 50 1 x Z 64	4 x 50 1 x Z 80	3 x 50 1 x Z 80	2 x 50 1 x Z 80	1 x 50 1 x Z 80	1 x 50 1 x Z 80	1 x 100	1 x 200	4 x 141 1 x Z 125	6 x 141 1 x Z 125
1 : 5	7 x 50 1 x Z 64	6 x 50 1 x Z 64	5 x 50 1 x Z 64	5 x 50 1 x Z 80	4 x 50 1 x Z 80	3 x 50 1 x Z 80	2 x 50 1 x Z 80	2 x 50 1 x Z 80	1 x 50	1 x 100	1 x 249 1 x Z 125	4 x 141 1 x Z 125
1 : 2	9 x 50	8 x 50	6 x 50 1 x Z 51	6 x 50 1 x Z 64	6 x 50 1 x Z 64	5 x 50 1 x Z 64	4 x 50 1 x Z 64	3 x 50 1 x Z 64	3 x 50 1 x Z 80	2 x 50 1 x Z 80	1 x 50 1 x Z 80	1 x 100 1 x Z 200
1 : 1	10 x 50	9 x 50	8 x 50	7 x 50 1 x Z 64	6 x 50 1 x Z 64	5 x 50 1 x Z 64	4 x 50 1 x Z 64	4 x 50 1 x Z 64	3 x 50 1 x Z 80	2 x 50 1 x Z 80	1 x 50 1 x Z 80	1 x 100

Wiedergabefaktoren 200, 141, 100, 70, 50 = mit DIN-Stufen-Tastatur

Wiedergabefaktoren Z 249, Z 125, Z 80, Z 64, Z 40 = manuelle Zoom-Einstellung

